

**New Hope Church Sound Setup Sheet - FOR -**

<b>Channel</b>	<b>PERSON or INSTRUMENT</b>	<b>WITH</b>	<b>Mixer Notes</b>
1	<b>WIRELESS MIC 1 (E6 or Lav only)</b>	Pre wired	Stereo
2	<b>WIRELESS MIC 2 Handheld or Lav</b>	Pre wired	Stereo
3	<b>Stage Wired</b>		Stereo
4	<b>REVERB Return</b>		M4
5	<b>FEMALE VOCALS</b>		M4
6	<b>FEMALE VOCALS</b>		M4
7	<b>FEMALE VOCALS</b>		M4
8	<b>MALE VOCALS</b>		M4
9	<b>MALE VOCALS</b>		M4
10	<b>MALE VOCALS</b>		M4
11	<b>LAPTOP/IPOD LEFT</b>	Pre wired	Stereo
12	<b>LAPTOP/IPOD RIGHT</b>	Pre wired	Stereo
13\14	<b>DVD</b>	Pre wired	Stereo
15\16	<b>CD IN</b>	Pre wired	Stereo
17	<b>KICK DRUM</b>	AKG D112	M1
18	<b>SNARE</b>	SM57	M1
19	<b>OVERHEAD or Toms</b>		M1
20	<b>OVERHEAD or Jimbe</b>		M1
21	<b>KEYBOARD L</b>		M2
22	<b>KEYBOARD R</b>		M2
23	<b>ACOUSTIC #1</b>		M3
24	<b>ELECTRIC #1</b>		M3
25	<b>ACOUSTIC #2</b>		M3
26	<b>ELECTRIC #2</b>		M3
27	<b>BASS GUITAR</b>		M3
28	<b>SAX</b>		M2
29	<b>Trumpet</b>		M2
30	Spare		
31	Spare		
32	Spare		

<b>Returns</b>	<b>FOR</b>	<b>With</b>	<b>Notes</b>
M1	Subgroup\recording <b>Drums, Bass</b>		
M2	Subgroup\recording <b>Keys, Brass</b>		
M3	Subgroup\recording <b>Guitar, Cello, Bass</b>		
M4	Subgroup\recording <b>Vocals</b>		

M5	Stage monitors		Pre
M6	Stage monitors		Pre
M7	Stage monitors		Pre
M8	Stage Monitors		Pre
M9	Subs		Post
M10	Reverb\Effects		Post
Stereo1 L	FOH		
Stereo1 R	FOH		
Stereo2 L	Recording		
Stereo2 R	Recording		
Matrix 1	Nursery/DVD Record		
Matrix 2	Nursery/DVD Record		
Aux 1 RTN	VCR		
Aux2 RTN	Computer		
Aux3 RTN			
Aux4 RTN			